



= NICE ROA37 Control Board.

= Power: 220V

= DIP Switch Function

= Receiver Configuration