



= OKEY SUB44WR 4Ch Remote.

= Number of Button : 4.

= Coding: Rolling Code.

= Frequency: 433.92 MHz.

= Programing: In Receiver.

= Power Supply: 12V, 23A.