



= Push Button Switch.

= Number of Switch: 1.

= Type: Micro Switch

= Only Push For Operate No Need for Long Press.