



- = RIB SUN 4Ch Remote.
- = Number of Button : 4.
- = Coding: Rolling Code.
- = Frequency: 433.92 MHz.
- = Programing: In Receiver.
- = Power Supply: 12V, 23A.